




## Step 1: Capture Tee Markers



## Step 2 : Capture Hole Location



## Step 3 & 4 : Display Distances



1. Place Tee Marker Pucks at center of each tee box (Black, Blue, etc.).

2. **1** Press Tee Switch once with golf tee and status light will change to **BLUE**.

3. Repeat with each Puck and leave in position on each tee box.

1. Place Hole Puck (with flagstick icon) next to the hole/pin location.

2. **2** Press Tee Switch once with golf tee and status light will change to **GREEN**. Light will begin flashing. Wait 2-3 minutes until light turns OFF.

3. Take Hole Puck and head to tee boxes.

4. Pick up Tee Marker Pucks. **BLUE** status lights should now be OFF.

1. Place all pucks (Tee & Hole) close to Board.

2. **3** Press and hold Tee Switch on all Pucks for two seconds until status lights turn **RED**.

3. **4** Press Tee Switch on Board once.

4. Board beeps and shows arrows next to positions when information is captured from pucks.

5. Once information is captured correctly from pucks a smiley face will display next to each position and **RED** lights on pucks will go OFF.